

Calibrating the backgauge on the Ideal 7228-90 EC 2 and EC 3

=====

1. Turn main switch on and press "Start" button. The backgauge moves to its "Set" position(If not, press and hold "Start" button as long as the backgauge reaches its "Set" position). Move backgauge forward until approx. 30 cm(11.82"). Press and hold switch "mm/inch" and green button "reverse" simultaneous. Release switch "mm/inch" and green button "reverse" simultaneous. The display will disappear. If not, repeat the procedure as long as the display will disappear. The memory will be completely erased.
2. Press "Start" button. the backgauge moves to its "Set" position(If not, press and hold "Start" button as long as the backgauge reaches its "Set" position). Move backgauge forwards until approx. 30 cm(11.82"). Use a pile of paper and make a cut. Measure the paper and insert the correct size of the paper into the display.
3. Press and hold switch "mm/inch", then press and hold button number "9". Release switch "mm/inch", then release button number "9". the machine is now adjusted electronically to the correct size.
4. Cut paper again and measure it, to confirm that size is correct.

Important : Press and hold switch "mm/inch" correctly, otherwise the display changes from metric to inch.

Measurment in metric is two digit	72.00 cm
Measurment in Inch is three place	28.000 "